



EchoCloud Ziggy Installation Guide

Note: Please read the entire Installation Guide before application.

The installation guide is intended to provide installers with helpful information regarding EchoCloud Ziggy prior to installing the material. Kirei accepts no responsibility for installation actions taken or not taken. This installation guide is not intended to be an in-depth guide; installer's knowledge as an experienced tradesman needs to be applied.

This installation guide serves only as a recommendation for installing and handling EchoCloud Ziggy. If you have questions about application or techniques, contact Kirei at www.kireiusa.com or 619.236.9924.

Installation

1. Unfold and lay flat on clean flat surface with V-cuts facing up.
2. Begin installing the aluminum tube or wood dowel by lifting the first flap of the element at the first hinge point and insert the tube or dowel to the first hole from the outside toward the center.
3. Continue folding the element in an accordion fashion and inserting the tube or dowel into the holes as you fold.
4. When you build up friction to the point that it becomes difficult to push through, switch sides and begin on the other aluminum tube or wood dowel.
5. Keeping the folds even will reduce friction and allow the tubes or dowels to slide more freely.
6. Once both aluminum tubes or wood dowels are installed and centered, insert provided endcaps to both sides of both tubes or dowels.
7. Placement of cable attachment points should be left to the installer's best judgment.
8. Using 3/64" looped aircraft cable, loop around aluminum tube or wood dowel and feed straight end through loop. (Cable length will vary based on install and ceiling height.)
9. Attach the straight end of the cable to a gated griper (or other terminal hardware) and attach to ceiling.
10. Make any necessary adjustments to level the element.

Work Safety

In the interest of work safety, it is recommended that people working with EchoCloud Ziggy wear the appropriate safety equipment. Although the product emits zero off-gases, masks and gloves should be worn to ensure the maximum possible safety precautions. For an SDS form, please contact Kirei at info@kireiusa.com or 619-236-9924.

Final Note

Kirei will not be responsible for any cutting or mounting not performed by Kirei staff.

For any other questions or concerns, please contact Kirei.